LAMINEX® LOCKER SYSTEMS



Fix hinge blocks to the right side panel using Euro-screws.

Fix catch plates to left side panel using $6 \times 1/2$ " screws.

Hints:

To avoid snapping heads off screws and stripping out board, set the cordless drill to a low torque setting.

When screwing into compact laminate, drive the screw ¾ of the way in, back the screw off, then gently drive the screw home.





STEP 2

Lay 15-16mm particle board strip on a flat surface. Lay back panel on particle board strip.

Ensuring that the back is the right way up, insert back into rebate on each side panel and screw off each end then the middle screws using 4.5x50mm screws.







Fix top and bottom panels into side and back rebates. Top panels may have holes for coat hook.



STEP 4

Note for correct positioning if shelves are pre-drilled for coat hooks.
Slide shelves into correct rebates.
Screw off shelves.

Turn unit onto its side and screw fix shelves through back.





Position the plinth on the floor and check for level. Place packing under the low points.





STEP 6

Fix angle brackets to the inside of the plinth and floor.

Silicone the 450x50mm aluminium cover strip to both ends of the plinth.





Use male and female connector bolts to join lockers together (holes are predrilled).

Use the male connector bolt to attach end panels. It will cut its own thread in the end panel.

Secure to the wall by screwing through the back panel of the lockers.





STEP 8

Screw hinges to doors and fit. Adjust hinges where required. Fit locks.

Hints:

To avoid snapping heads off screws and stripping out board, set the cordless drill to a low torque setting.

When screwing into compact laminate, drive the screw ³/₄ of the way in, back the screw off, then gently drive the screw home.







Also available in the Laminex® partitioning range:





















For more inspiration join us on facebook.com/thelaminexgroupau

For a sample call 1800 002 204. For more information visit laminex.com.au or call 132 136