

LAMINEX® CLIPWALL™

FACTSHEET – CARE & MAINTENANCE

CLEANING

- A wipe over with a clean, soft damp cloth should be sufficient to keep the decorative surface clean.
- Soiled surfaces or light stains are removed with warm soapy water or with common detergent such as Windex glass cleaner, Mr Muscle, Dissol, Nifty solvent or bathroom cleaner, Flash liquid, or Bathroom Plus, which do not contain abrasive, strongly acidic, or alkaline ingredients.
- Noticeable wipe marks are generally due to greasy residue moved around during cleaning.

Methylated spirits or Windex glass cleaner may be used to remove these.
- A final wipe down with clean soapy water and a dry clean cloth is recommended to remove residue, and restore appearance. Other cleaning products like Quartet Board Gear are also available.
- Do not saturate surface with water or cleaning products.
- Laminex does not supply these cleaning products. It is important that cleaning products are not applied to the raw substrate; only use it on the melamine decorative surface.

GENERAL

- Wipe off all spills immediately.
- Never use abrasive cleaners, powders, pads or steel wool, which can damage the surface.
- On textured finish surfaces, dirt may build up over time. To remove, use a soft nylon bristled brush (i.e. nail brush) and mild detergent.

To avoid surface scratches or marks, make sure the cleaning cloth does not contain any hard or foreign particles.
- Laminex Clipwall should not remain in contact with hypochlorite bleach, caustic solutions, hydrogen peroxide solution in any concentrations, mineral acid, sodium bisulphate, potassium permanganate in any concentrations, silver nitrate (1% concentration), berry juice, gentian violet in any concentration, mild silver protein, laundry blue dye, or iodine solution.