



Laminex® Impressions™ textured surfaces add extra dimension to any space. This sumptuous new range of textured surfaces deliver a luminous, tactile realism that creates a striking point of interest. Available in a selection of decors from the Laminex Colour Palette, surfaces are durable and easy to clean and maintain.

**Laminex**<sup>®</sup>  
Inspire your space



**LAMINEX® IMPRESSIONS™**  
TEXTURED SURFACES

For enquiries in Australia, call 132 136.  
If you require a sample, call 1800 002 204.  
**[laminex.com.au](http://laminex.com.au)**

**Laminex**<sup>®</sup>  
Inspire your space



**LAMINEX® IMPRESSIONS™**  
TEXTURED SURFACES





## CARE AND MAINTENANCE

### Cleaning

- A wipe over with a clean, soft damp cloth should be sufficient to keep the decorative surface clean.
- Soiled surfaces or light stains are removed with warm soapy water or with common detergent such as Windex glass cleaner, Mr Muscle, Dissol, Nifty solvent or bathroom cleaner, Flash liquid, or Bathroom Plus, which do not contain abrasive, strongly acidic, or alkaline ingredients.
- Noticeable wipe marks are generally due to greasy residue moved around during cleaning. Methylated spirits or Windex glass cleaner may be used to remove these. A final wash down

with clean soapy water and a dry clean cloth is recommended to remove residue, and restore appearance. Other cleaning products like Quartet Board Gear are also available.

- The Laminex Group does not supply these products. It is important that this product is not applied to the raw substrate; only use it on the laminate and melamine decorative surface.

### General

- Wipe off all food and drink spills immediately.
- Never use abrasive cleaners, powders, pads or steel wool, which can damage the surface. As with all textured finish surfaces, dirt may

build up over time. To remove, use a soft nylon bristled brush (i.e. nail brush) and mild detergent.

- To avoid surface scratches or marks, make sure the cleaning cloth does not contain any hard or foreign particles.

**Laminex Impressions should not remain in contact with hypochlorite bleach, caustic solutions, hydrogen peroxide solution in any concentrations, mineral acid, sodium bisulphate, potassium permanganate in any concentrations, silver nitrate (1% concentration), berry juice, gentian violet in any concentration, mild silver protein, laundry blue dye, or iodine solution.**